



USER INSTRUCTIONS

3760 Digital Combination Lock

For full fitting, operating and programming instructions please visit
www.loweandfletcherinc.com

Lowe & Fletcher Inc
650 Airport Place Norton Shores
MI-49441

T: +1 (616) 994 0490

F: +1 (616) 994 0480

E: sales@loweandfletcherinc.com

W: www.loweandfletcherinc.com

Public Mode

Turn Handle to Locked Position

Lock

USER CODE



USER CODE



Unlock

USER OR
MASTER CODE



Private Mode

Unlock

USER OR
MASTER CODE



Lock

Turn to Lock
Position



Change User Code

#



OLD USER CODE



02



NEW USER CODE



NEW USER CODE



Error



Errors will time-out after 4 seconds.

Unfinished instructions will time-out after 4 seconds.

Always wait for LED lights to finish before pressing next key.