

X

0

3

5

Cam

) 2 ()

• 4

) **b**

8



Access to the DCL can be gained if the code is not known or the batteries have died.

Using the override key, insert the key into the lock and turn 90 degrees.

Access can now be gained to locker.

Note, the Cam is connected to the barrel. The handle will not turn.





