



USER INSTRUCTIONS PUBLIC MODE

3790 Digital Combination Lock

Lowe & Fletcher Inc.
650 Airport Place
Norton Shores
MI-49441

T: + 1 (616) 994 0490
F: + 1 (616) 994 0480
E: sales@loweandfletcherinc.com
W: www.loweandfletcherinc.com



USER INSTRUCTIONS PUBLIC MODE

3790 Digital Combination Lock

Lock

ENTER CODE



CONFIRM CODE



LIFT HATCH ENSURE
LOCKING

Unlock

LIFT HATCH TO OPEN



Error



Errors will time-out after 4 seconds.

Unfinished instructions will time-out after 4 seconds.

Always wait for LED lights to finish before pressing next key.

USER INSTRUCTIONS PUBLIC MODE

3790 Digital Combination Lock

